





0 2 3 4 9 DO NOT USE THIS PROCEDURE IF THE MAINS IS NOT AVAILABLE. IF IN ANY DOUBT CONTACT YOUR UPS SERVICE PROVIDER. STEP K (ON BYPASS POSITION) STEP L STEP M STEP N STEP 0 THIS PROCEDURE ASSUMES: ⊖ MANUAL BYPASS ⊖ ⊖ MANUAL BYPASS ⊖ ⊖ MANUAL BYPASS ⊖ ALL SWITCH'S ON THE EMBS AND ON THE UPS UNIT SHOULD STILL BE AS PER STEP J ON THE PREVIOUS PAGE PRIOR TO PROCEDING THE UPS UNIT SHOULD BE IN STATIC BYPASS AND SHOULD BE READY TO ACCEPT THE SYSTEM LOAD В IF IN ANY DOUBT CONTACT YOUR UPS SYSTEM SERVICE PROVIDER UPS UPS UPS **BEFORE PROCEDING** ⊖ OUTPUT OUTPUT ⊖ OUTPUT MANUAL BYPASS: -IN THE ON POSITION MANUAL BYPASS: MANUAL BYPASS: MANUAL BYPASS: MANUAL BYPASS: -IN THE ON POSITION -IN THE ON POSITION -IN THE ON POSITION -IN THE ON POSITION INTERLOCK KEY: -INSERTED + TURNED CLOCKWISE INTERLOCK KEY: INTERLOCK KEY: INTERLOCK KEY INTERLOCK KEY: -INSERTED + TURNED ANTI-CLOCKWISE -REMOVED -REMOVED -REMOVED UPS OUTPUT: С -IN THE OFF POSITION UPS OUTPUT: UPS OUTPUT: UPS OUTPUT: UPS OUTPUT: -IN THE OFF POSITION -IN THE OFF POSITION -IN THE OFF POSITION -IN THE ON POSITION -INVERTER RUNNING - LOAD ON MAINS UPS UNIT: UPS UNIT: UPS UNIT: UPS UNIT: -STATIC BYPASS - LOAD ON MAINS STEP P STEP R STEP S STEP Q STEP T D D REFER TO UPS USER MANUAL TO SWITCH ⊖ MANUAL BYPASS ⊖ THE UPS UNIT (OR UNITS) TO ONLINE BYPASS BYPASS ONCE UPS UNIT (OR UNITS) ARE ONLINE THE SEQUENCE IS COMPLETE AND THE LOAD IS NOW BACKED UP BY UPS IF IN ANY DOUBT CONTACT YOUR UPS SERVICE PROVIDER MANUAL BYPASS: Ε -IN THE OFF POSITION UPS UPS UPS OUTPUT 0 ⊖ UPS ⊖ OUTPUT INTERLOCK KEY: -INSERTED + TURNED CLOCKWISE MANUAL BYPASS: MANUAL BYPASS: MANUAL BYPASS: MANUAL BYPASS: UPS OUTPUT: -IN THE OFF POSITION -IN THE OFF POSITION -IN THE OFF POSITION -IN THE ON POSITION -IN THE ON POSITION INTERLOCK KEY INTERLOCK KEY INTERLOCK KEY: INTERLOCK KEY UPS UNIT: -REMOVED -REMOVED -INSERTED + TURNED ANTI-CLOCKWISE -INSERTED + TURNED CLOCKWISE -ONLINE - LOAD ON UPS UPS OUTPUT UPS OUTPUT: UPS OUTPUT: UPS OUTPUT: -IN THE ON POSITION -IN THE ON POSITION -IN THE ON POSITION -IN THE OFF POSITION UPS UNIT: UPS UNIT: UPS UNIT: UPS UNIT: -STATIC BYPASS - LOAD ON MAINS REV NO: PRODUCT REF: RB1-EMBS-125A-1P-ISO 1) PRODUCT MUST BE INSTALLED IN COMPLIANCE WITH ALL NATIONAL AND LOCAL ELECTRICAL REGULATIONS DOCUMENT NUMBER: RBECAD-00082 CREATION DATE: 29/04/2016 2) PLEASE REFER TO UPS PRODUCT MANUALS FOR ADDITIONAL INFORMATION PAGE DESCRIPTION: INTERLOCK OPERATION PAGE 2 REV DATE: 25/05/2016 3) ALL DIMENSIONS IN MM UNLESS OTHERWISE SPECIFIED PROJECT NO: SUBMITTAL DRAWING DRAWN BY: R BARNES 4) 4 - CORE SHIELDED SIGNAL CABLE MUST BE RUN FROM EMBS TO EACH UPS UNIT PAGE TEMPLATE REF: RBQS00078REV2 CHECKED BY: M BRADLEY 5) ALL DASHED LINES EXTERNAL TO BYPASS PANEL PRODUCT WEIGHT: SHEET NUMBER: 4 OF 5 20KG

